



Remarks:

- 1. All dimensions in mm.
- 2. Side view of foundations is from inside of property.
- 3. Prepare view of foundation with concret class C25. Concter must be reinforced with fibres and flat on top.
- 4. For gate installation use anchors M16x240 or longer. Anchors must be over concete surface 80mm minimum
- 5. Use this drawing as suggestion. Exact foundation dimensions have to be verified concerning local soil parameteres and freeze depth.

HALSANG

Halsäng Stängsel AB Halsäng 4 521 93 Falköping SWEDEN www.halsang.se

					www.nacsang.se	
Material		Coating	Width		Height	
Main post		Frame	Reinforcement		Infill	
Designed by I. Stechty		Edited by	Date 2018-07-10		Order number	
Scale 1:24	Format A3	Drawing ODEN FP 6000 Right		Number SLG.O.F.6.2.R		